

## Spectralink 7522/7532 Handset

### Quick Start Guide



14226903-IG Ed. 6.0, Original document

Charge your handset for 5 hours prior to first use for best performance.

#### Turning Handset On

- Press left softkey to turn on handset.

#### Turning Handset Off

1. Press left softkey until the question 'Turn off?' appears in display.
2. Press **Yes** to confirm.

#### Adjusting Speaker/Headset Volume

- While on call, press the keys placed at the upper right side of the handset for volume control.



#### Adjusting Ringing Volume

1. Press **Menu** to enter main menu.
2. Scroll to **Settings**, and press **Select**.
3. Scroll to **Ringing volume**, and press **Select**.
4. Press the **left or right side of the navigation key** to adjust the volume of the ring tone.
5. Press **Set**.



#### Changing Ringing Tone

1. Press **Menu** to enter main menu.
2. Scroll to **Settings**, and press **Select**.
3. Scroll to **Ringing tone**, and press **Select**.
4. Scroll to the desired ring tone, and press the **right side of the navigation key** to listen to the ring tone.
5. Press the **left side of the navigation key** to listen to the internal calls ring tone.
6. Scroll to the desired ring tone, and press **Change** to select the new ring tone.

#### Off Hook Dialling (Dial Directly)

1. Press .
2. Dial number.
3. Press  to end the call.

#### On Hook Dialling (Pre-Dial)

1. Dial number.
2. Press .
3. Press  to end the call.


#### Speed Dial Calls

- Press and hold a key (0-9) for three seconds, until the call is initiated.

#### Answering and Ending Calls

- To answer or end a call, press .


#### Call List Calls


1. Press the **left side of the navigation key** to enter **Call List**.
2. Scroll to the desired name or number, and press .

#### Call Missed calls

1. Press the **right side of the navigation key** to enter **Missed Call List**.
2. Scroll to the desired name or number, and press .

#### Phone Book Calls

1. Press the **bottom of the navigation key** to enter phonebook.
2. Scroll to the desired name and press  to make a call.



### Adding a New Contact to Phone Book

1. Press **Menu** to enter main menu.
2. Scroll to **Phone Book**, and press **Select**.
3. Scroll to **Add name/number**, and press **Select**.
4. Type the name of the contact using the keys 0-9.
5. Scroll to number, and enter the directory number/SIP extension of the contact (max. 24 digits/64 characters). Before entering a SIP URI, press and hold **#** until **SIP:** is shown.
6. Press **Save** to store name and directory number/SIP extension.

If the display shows **Memory full**, it is necessary to delete one or more contacts from phone book.

### Assigning Speed Dials

1. Press **Menu** to enter main menu.
2. Scroll to **Phone Book**, and press **Select**.
3. Scroll to **Speed dial**, and press **Select**.
4. Scroll to the desired speed dial, and press **Add name**.
5. Scroll to desired number, and press **Ok**.

### Locking/Unlocking Keypad

- Press left softkey followed by \* button to lock or unlock the keypad.

### Silent Mode On/Off

- Press **Menu**, followed by the **#** button to turn the handset silent mode on/off. In silent mode there is no sound for incoming calls and notifications.

### Exit Menus

- Exit menus and return to home screen, press **R**.

### Speakerphone On/Off

1. While on a call, press **Options**, scroll to **Spkr. on** to enable speakerphone.
2. To disable speakerphone, press **Options**, scroll to **Spkr. off** to disable speakerphone.

### Microphone Mute On/Off

1. While on a call, press **Mic Mute** to turn microphone mute on.
2. To turn microphone mute off, press **Mic on**.

### Technical Specifications

#### Capacity Spectralink 7522 and 7532

- Active talking time (Economy mode) up to 21 hours.
- Standby time Spectralink 7522 up to 122 hours.
- Standby time Spectralink 7532 up to 115 hours.

#### Capacity Spectralink 7532 with Bluetooth Turned on

- Active talking time up to 14 hours.
- Standby time up to 114 hours.

#### Temperature

- Charging temperature: 0° - 40°C/32° - 104°F
- Operating temperature: 0° - 40°C/32° - 104°F

### Handset Icons



Missed call



Incoming calls



Battery charging (in charger)



Battery charging (handset turned on in charger)



Battery capacity decreasing (handset out of charger)



Battery capacity low



Message received



Keypad locked



Silent mode



Appears when loudspeaker is turned on



Microphone muted

© 2013 - 2018 Spectralink Corporation All rights reserved. Specifications subject to change without notice.

US Location  
+ 1 800-775-5330

Spectralink Corporation  
2560 55th Street  
Boulder, CO 80301  
USA

[info@spectralink.com](mailto:info@spectralink.com)

Denmark Location  
+45 75602850

Spectralink Europe ApS  
Bygholm Søpark 21 E Stuen  
8700 Horsens  
Denmark

[infoemea@spectralink.com](mailto:infoemea@spectralink.com)

[www.spectralink.com](http://www.spectralink.com)